

EZ to Install... EZ to Use

1. First locate a spot on your motorcycle, ATV or equipment to attach the Hot Spot Heater with it's suction cup.



2. Wire plug "A" to your utility switch on your vehicle. Affix wiring harness so as not to be noticeable and safe from hot exhaust and chafing.



3. Affix Intake hose with clip to cylinder cooling vane at rear of engine to pick up hot air. Attach hose to heater blower port marked "IN".



4. Attach discharge hose to "OUT" port of blower motor and place other end under your jacket and turn switch to ON and ride in warm comfort.



5. When not in use, unplug unit and store until another cold day.



SP & T, INC.

1920 Northgate Blvd. • Suite A-8 • Sarasota, FL 34234

www.hotspotheater.com

941-351-0500 • Toll Free 877-230-HEAT

ORDER ONLINE